

Flight Plans

Creating a Flight Plan (Spelling method)

The G-1000 can store up to 99 numbered flight plans. Additionally each of the stored Flight Plans can be used in reverse and each one can contain up to 31 waypoints. Unlike Direct to mode, the Flight Plan Mode requires you to enter an identifier for the starting point. Three methods of creating Flight Plans are the **Spelling**, **Point-n-Shoot** and the **Most Recent List** method.

- 1 PRESS **FPL**. Opens the Active Flight Plan window (FPL1).
- 2 ROTATE Small FMS Knob one click clockwise to display the Flight Plan Catalog (FPL2).
- 3 PRESS **NEW** ▲ soft key to open the Stored Flight Plan window.
- 4 ROTATE Small FMS Knob 2 clicks clockwise to display the first character of the first waypoint identifier. (The default first letter is “**K**”).
- 5 ROTATE Large FMS Knob to move the cursor to the next character.
- 6 ROTATE Small FMS Knob to select the character’s value.
- 7 Continue with steps #5 and #6 to spell out the rest of the waypoint identifier.
- 8 PRESS **ENT**. The flashing cursor moves to the next line in the Stored Flight Plan window.
- 9 Repeat steps #4 through #8 to spell out the rest of the waypoints in the flight plan.
- 10 When finished PRESS **MENU** to open the Options window. (This same window allows you to INVERT, DELETE, or REMOVE Departure).
- 11 If necessary ROTATE the Large FMS Knob to highlight the “**Store Flight Plan**” option and PRESS **ENT**
- 12 PRESS **ENT** to store the flight plan.
- 13 PRESS the small FMS Knob to return to the Flight Plan Catalog Page with the flight plan listed.